2. 各部の名称と設定

2. Parts Names and Settings



unit : mm (inch)

No.	名称	内　容	
①	動作表示 LED	LED 名	確認内容
		PW	点灯：電源 ON，消灯：電源 OFF。
		L RUN	点灯：交信正常時。 消灯：交信断時（タイムオーバエラー）。
		L ERR.	点灯：交信エラー時。 一定間隔で点滅： 通電中に局番設定・伝送速度設定スイッチの設定を変更したとき。 不定間隔で点滅： 終端抵抗の設定が違っている，ユニット，CC-Link 専用ケーブルがノイズの影響を受けているとき。 消灯：交信正常時。
		Y0～1F	点灯：出力 ON，消灯：出力 OFF。
②	伝送速度設定	（下表参照） 伝送速度は必ず上記の範囲で設定してください。	
③	局番設定スイッチ	STATION NO.の“10”，“20”，“40”で局番の 10 の位を設定します。 STATION NO.の“1”，“2”，“4”，“8”で局番の 1 の位を設定します。 局番は必ず 1～64 の範囲で設定してください。(＊1) (例) 局番を“10”に設定するときは，下記のようにスイッチ設定を行います。	
④	端子台	出力ユニット電源，伝送，出力信号の接続用端子台です。	
⑤	DIN レール用フック	ユニットを DIN レールに取り付けるときに DIN レール用フックの中心線上を指でカチッと音がするまで押さえます。	

② 伝送速度設定:

設定値	設定スイッチ状態			伝送速度
	4	2	1	
0	OFF	OFF	OFF	156 kbps
1	OFF	OFF	ON	625 kbps
2	OFF	ON	OFF	2.5 Mbps
3	OFF	ON	ON	5.0 Mbps
4	ON	OFF	OFF	10 Mbps

③ 局番設定スイッチ:

局番	十の位			一の位			
	40	20	10	8	4	2	1
10	OFF	OFF	ON	OFF	OFF	OFF	OFF

＊1 局番を重複して設定することはできません。

No.	Item	Description	
①	Operating status indicator LEDs	LED name	Confirmation details
		PW	On : Power supply on. Off : Power supply off.
		L RUN	On: Normal communication. Off: Communication cutoff (time expiration error).
		L ERR.	On: Communication data error. Flicker at regular intervals: Indicates that the station number setting or transmission speed setting switch position was changed while power is on. Flicker at irregular intervals: When the connection of the terminal resistor was forgotten; when the cable for the module, CC-Link is receiving noise influence. Off: Normal communication.
		Y0 to 1F	On: OUTPUT ON, Off: OUTPUT OFF.
②	Trans-mission speed setting	(see table below) Be sure to set the transmission speed within the above range.	
③	Station number setting switches	Select “10”, “20” or “40” to set the ten’s place of the station number. Select “1”,“2”,“4” or “8” to set the one’s place of the station number. Always set the station number within the range of 1 to 64. (*1) (Example) Set the switches as below when setting the station number to 10:	
④	Terminal block	A terminal block for connection to the power supply, transmission and output signals.	
⑤	Hook for DIN rail	When the module is installed to the DIN rail, push on the center line of the hook for DIN rail with a finger tip until a clicking sound is heard.	

② Transmission speed setting:

Setting value	Setting switch status			Transmission speed
	4	2	1	
0	OFF	OFF	OFF	156 kbps
1	OFF	OFF	ON	625 kbps
2	OFF	ON	OFF	2.5 Mbps
3	OFF	ON	ON	5.0 Mbps
4	ON	OFF	OFF	10 Mbps

③ Station number setting switches:

Station number	Ten’s place			One’s place			
	40	20	10	8	4	2	1
10	OFF	OFF	ON	OFF	OFF	OFF	OFF

＊1 Duplicate station number cannot be set.

本マニュアルは再生紙を使用しています。
Printed in Japan on recycled paper.

MITSUBISHI ELECTRIC CORPORATION
HEAD OFFICE : MITSUBISHI DENKI BLDG MARUNOUCHI TOKYO 100-8310 TELEX : J24532 CABLE MELCO TOKYO

IB番号 IB No.	IB-0800358-A
形名 Model	AJ65SBTB1-32TE1-U-HW

AJ65SBTB1-32TE1 形 CC-Link システム小形タイプリモート I/O ユニットユーザーズマニュアル

AJ65SBTB1-32TE1 CC-Link System Small Type Remote I/O Module User’s Manual

● 安全上のご注意 ●

（ご使用前に必ずお読みください）

本製品のご使用に際しては，本マニュアルをよくお読みいただくと共に，安全に対して十分に注意を払って，正しい取扱いをしていただくようお願いいたします。

なお，この注意事項は本製品に関するもののみについて記載したものです。シーケンサシステムとしての安全上のご注意に関しては，CPU ユニットのユーザーズマニュアルを参照してください。

この●安全上のご注意●では，安全注意事項のランクを「危険」，「注意」として区分してあります。

⚠危 険	取扱いを誤った場合に，危険な状況が起こりえて，死亡または重傷を受ける可能性が想定される場合。
⚠注 意	取扱いを誤った場合に，危険な状況が起こりえて，中程度の傷害や軽傷を受ける可能性が想定される場合および物的損害だけの発生が想定される場合。

なお，⚠注意に記載した事項でも，状況によっては重大な結果に結びつく可能性があります。

いずれも重要な内容を記載していますので必ず守ってください。

本マニュアルは必要なときに読めるように大切に保管すると共に，必ず最終ユーザまでお届けいただくようにお願いいたします。

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using this equipment, thoroughly read this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to this equipment. Refer to the CPU module user’s manual for a description of the PC system safety precautions.

These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: ”DANGER” and “CAUTION”.

⚠DANGER	Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.
⚠CAUTION	Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by ⚠ CAUTION may also result in to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

(0609)MEE

【設計上の注意事項】

⚠危 険

- データリンクが交信異常になったとき，交信異常局は次のような状態になります。
  交信状態情報を使って，システムが安全側に働くようにシーケンスプログラム上でインタロック回路を構成してください。
  誤出力，誤動作により事故の恐れがあります。
  リモート I/O 局からの出力は，全点 OFF します。
- リモート I/O ユニットの故障によっては，出力が ON 状態または OFF 状態になることがあります。重大な事故につながるような出力信号については，外部で監視する回路を設けてください。

⚠注 意

- ユニットは，CPU ユニットユーザーズマニュアル記載の一般仕様の環境で使用してください。
  一般仕様の範囲以外の環境で使用すると，感電，火災，誤動作，製品の損傷あるいは劣化の原因になります。
- 制御線や通信ケーブルは，主回路や動力線などと束線したり，近接したりしないでください。
  100mm 以上を目安として離してください。
  ノイズにより，誤動作の原因になります。

【取付け上の注意事項】

⚠注 意

- ユニットの導電部分には直接触らないでください。
  ユニットの誤動作，故障の原因になります。
- ユニットは，DIN レールまたは取付けネジにて，確実に固定し，取付けネジは規定トルク範囲内で確実に締め付けてください。
  ネジの締付けがゆるいと，落下，短絡，誤動作の原因になります。
  ネジを締め過ぎると，ネジの破損による落下，短絡の原因になります。

【配線上の注意事項】

⚠危 険

- 配線作業などは，必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断しないと，感電あるいは製品の損傷の恐れがあります。

【DESIGN PRECATUIONS】

⚠DANGER

- When a communication error occurs in the data link, the communication error station will be in the following condition. Configure an interlocking circuit in a sequence program using the communication status information so that the safety of the overall system is always maintained.
  Accident may occur due to output error or malfunctioning.
  Output points from remote I/O station will be all switched off.
- Output could be switched on or off when a problem occurs in the remote I/O modules. So build an external monitoring circuit that will monitor any output signals that could cause a serious accident.

⚠CAUTION

- Use each module in an environment as specified in the “general specification” in the CPU module user’s manual. Usage of the module outside the general specification range may cause electric shock, fire, malfunction, product damage or deterioration.
- Do not have control cables and communication cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.

【INSTALLATION PRECAUTIONS】

⚠CAUTION

- Do not directly touch the module’s conductive parts.
  Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the specified torque range. Loose terminal screws may cause a short circuit or erroneous operation. If the terminal screws are too tight, it may cause falling, short circuit or erroneous operation due to damage of the screws.

【WIRING PRECAUTIONS】

⚠DANGER

- Completely turn off the externally supplied power used in the system when installing or placing wiring. Not completely turning off all power could result in electric shock or damage to the product.

⚠注 意

- FG 端子はシーケンサ専用の D 種接地（第三種接地）以上で必ず接地を行ってください。
  感電，誤動作の恐れがあります。
- 空き端子ネジは必ず締付けトルク範囲（42～50N･cm）で締付けてください。
  圧着端子と短絡する原因になります。
- 圧着端子は適合圧着端子を使用し，規定のトルクで締付けてください。
  先開形圧着端子を使用すると，端子ネジがゆるんだ場合に脱落し，故障の原因になります。
- ユニットの配線は，製品の定格電圧および端子配列を確認した上で正しく行ってください。
  定格と異なった電源を接続したり，誤配線すると，火災，故障の原因になります。
- 端子ネジの締付けは，規定トルク範囲内で行ってください。
  端子ネジの締付けがゆるいと，火災や誤動作の原因になります。
  端子ネジを締め過ぎると，ネジの破損による短絡，誤動作の原因になります。
- ユニット内に，切粉や配線クズなどの異物が入らないように注意してください。
  火災，故障，誤動作の原因になります。
- ユニットに接続する電線やケーブルは，必ずダクトに納める，またはクランプによる固定処理を行ってください。
  ケーブルをダクトに納めなかったり，クランプによる固定処理をしていないと，ケーブルのブラツキや移動，不注意の引っ張りなどによるユニットやケーブルの破損，ケーブルの接触不良による誤動作の原因となります。
- 制御線と通信ケーブルは束線したり，近接したりしないでください。
  ノイズにより，誤動作の原因になります。
- ユニットに接続されたケーブルを取り外すときは、ケーブル部分を手に持って引っ張らないでください。コネクタ付きのケーブルは，ユニットに接続している部分のコネクタを手で持って取り外してください。コネクタなしのケーブルは、ユニットに接続している部分のネジを緩めてから取り外してください。ユニットに接続された状態でケーブルを引っ張ると、ユニットやケーブルの破損,ケーブルの接続不良による誤動作の原因となります。

【立上げ・保守時の注意事項】

◇危 険

- 通電中に端子に触れないでください。
  感電の原因になります。
- 清掃,端子ネジ,ユニット取付けネジの増し締めは，必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断しないと，ユニットの故障や誤動作の原因になります。

⚠注 意

- ユニットの分解，改造はしないでください。
  故障，誤動作，ケガ，火災の原因になります。
- ユニットは落下させたり，強い衝撃を与えないでください。
  ユニットの破損の原因になります。
- ユニットの盤への取付け・取外しは必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断しないと，ユニットの故障や誤動作の原因になります。
- 端子台の着脱は，製品ご使用後，50 回以内としてください。
  （JIS B 3502 準拠）
- ユニットに触れる前には，必ず接地された金属などに触れて，人体などに帯電している静電気を放電してください。
  静電気を放電しないと，ユニットの故障や誤動作の原因になります。

【廃棄時の注意事項】

⚠注 意

- 製品を廃棄するときは，産業廃棄物として扱ってください。

1. 仕様

項目		内容
出力点数		32 点
絶縁方式		フォトカプラ絶縁
定格負荷電圧		DC12/24V
使用負荷電圧範囲		DC10.2～26.4V（リップル率 5%以内）
最大負荷電流		0.5A/1 点 4.8A/1 コモン
最大突入電流		1.0A　10ms 以下
OFF 時漏洩電流		0.1mA 以下
ON 時最大電圧降下		0.5V 以下（TYP）0.5A 0.8V 以下（MAX）0.5A
出力形式		ソースタイプ
応答時間	OFF→ON	0.5ms 以下
	ON→OFF	1.5ms 以下（抵抗負荷）
出力部 外部供給電源	電圧	DC10.2～26.4V（リップル率 5%以内）
	電流	15mA 以下（TYP.DC24V1 コモン当たり） 外部負荷電流は含まず
サージキラー		ツェナーダイオード
コモン方式		32 点 1 コモン （端子台形 1 線式）
占有局数		1 局 32 点割付（32 点使用）

⚠CAUTION

- Always ground the FG terminal.
  There is a risk of electric shock or malfunction.
- Be sure to tighten any unused terminal screws within a tightening torque range (42 to 50N･cm).
  Failure to do so may cause a short circuit due to contact with a solderless terminal.
- Use applicable solderless terminals and tighten them with the specified torque.
  If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.
- Fix terminal screws securely within the regulated torque. Loose terminal screws may cause fire and/or malfunction.
  If the terminal screws are too tight, it may cause short circuit or erroneous operation due to damage of the screws.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Be sure to fix the wires or cables by ducts or clamps when connecting them to the module. Failure to do so may cause damage of the module or the cables due to accidental pull or unintentional shifting of the cables, or malfunctions due to poor contact of the cable.
- Do not install the control lines together with the communication cables, or bring them close to each other. Failure to do so may cause malfunctions due to noise.
- When disconnecting a cable from the module, do not pull on the cable itself. Disconnect cables not fitted with a connectors by holding and pulling the cable connector. Disconnect cables not fitted with a connector by removing the screws from the part connected to the module can cause damage to the module or cable, or, malfunction due to cable connection faults.

【STARTING AND MAINTENANCE PRECAUTIONS】

◇DANGER

- Do not touch terminals when the power is on. Doing so could cause an electric shock.
- Switch off all phases of the externally supplied power used in the system when cleaning the module or retightening the terminal or module mounting screws. Not doing so could result in electric shock.

⚠CAUTION

- Never try to disassemble of modify module. It may cause product failure, malfunction, fire or cause injury.
- Do not drop or apply any strong impact to the module. Doing so may damage the module.
- Completely turn off the externally supplied power used in the system before mounting or removing the module to/from the panel. Not doing so could result in damage to the product.
- Do not install/remove the terminal block more than 50 times after the first use of the product. (IEC 61131-2 compliant)
- Always make sure to touch the grounded metal to discharge the electricity charged in the electricity charged in the body, etc., before touching the module.
  Failure to do say cause a failure or malfunctions of the module.

【DISPOSAL PRECAUTIONS】

⚠CAUTION

- When disposing of this product, treat it as industrial waste.

1. Specification

Item		Description
Number of output points		32 points
Isolation method		Photocoupler
Rated load voltage		12/24 VDC
Operating load voltage range		10.2 to 26.4 VDC (ripple ratio: within 5 %)
Max. load current		0.5 A/point 4.8 A/common
Max. inrush current		1.0 A 10 ms or lower
Leakage current at OFF		0.1 mA or lower
Max. voltage drop at ON		0.5 V or lower (TYP) 0.5 A 0.8 V or lower (MAX) 0.5 A
Output form		Source type
Response time	OFF→ON	0.5 ms or lower
	ON→OFF	1.5 ms or lower (Resistive load)
External Power supply for time	Voltage	10.2 to 26.4 VDC (ripple ratio : within 5%)
	Current	15 mA or lower (TYP.24 VDC/common) Not including external load current
Surge suppression		Zener diode
Wiring method for common		32 points/common (Terminal block single wire type)
Occupied station number		1 station 32 points assignment (use 32 points)

項目		内容
I/O ユニット電源	電圧	DC20.4～26.4V（リップル率 5%以内）
	電流	60mA 以下（DC24V，全点 ON 時）
ノイズ耐量		DC タイプのノイズ電圧 500Vp-p ノイズ幅 1μs，ノイズ周波数 25～60Hz のノイズシミュレータによる
耐電圧		DC 外部端子一括－アース間 AC500V1 分間
絶縁抵抗		DC 外部端子一括－アース間 DC500V 絶縁抵抗計にて 10MΩ 以上
保護等級		IP2X
質量		0.26kg
外部接続方式	通信部， I/O ユニット電源部	7 点 2 ピース端子台 ［伝送回路，I/O ユニット電源，FG］ M3×5.2　締付トルク 59～88N･cm 適合圧着端子の挿入枚数は 2 枚以内
	入出力電源部， 入出力部	34 点直付け端子台［入出力電源，I/O 信号］ M3×5.2　締付トルク 59～88N･cm 適合圧着端子の挿入枚数は 2 枚以内
ユニット取付けネジ		平座金みがき丸付 M4 ネジ (締付けトルク範囲 79～108N･cm) DIN レールでの取付け可，6 方向取付け可
適用 DIN レール		TH35-7.5Fe，TH35-7.5Al (JIS C 2812 に準拠)
適合圧着端子		・RAV1.25-3（JIS C 2805 に準拠） ［適合電線サイズ：0.3～1.25mm^2］ ・V2-MS3（日本圧着端子製造（株））， RAP2-3SL（日本端子（株））， TGV2-3N(（株）ニチフ) ［適合電線サイズ：1.25～2.0mm^2］

Item		Description
I/O module power supply	Voltage	20.4 to 26.4 VDC (ripple ratio : within 5%)
	Current	60mA or lower (When 24 VDC and all point is on)
Noise durability		DC type noise voltage 500Vp-p, noise width 1μs, noise carrier frequency 25 to 60Hz (noise simulator condition)
Withstand voltage		500 VAC for 1 minute between all DC external terminals and ground
Insulation resistance		10MΩ or higher measured with a 500 VDC insulation resistance tester
Protection of degree		IP2X
Weight		0.26kg
External wiring system	Communication area, I/O module power supply	7-point 2-piece terminal block [transmission circuit, I/O module power supply, FG] M3 x 5.2　Tightening torque: 59 to 88N･cm Applicable solderless terminals: 2 max.
	I/O power supply, I/O area	34-point direct-mount terminal block [I/O power supply, I/O signal] M3 x 5.2　Tightening torque: 59 to 88N･cm Applicable solderless terminals: 2 max.
Module installation screw		M4 screw with plain washer finished round (tightening torque range 79 to 108 N･cm)　DIN rails can be used for installation and can be installed in 6 directions
Applicable DIN rail		TH35-7.5Fe, TH35-7.5Al (conforming to IEC 60715)
Applicable solderless terminal		・ RAV1.25-3 (conforming to JIS C 2805) [Applicable wire size: 0.3 to 1.25mm^2] ・ V2-MS3,RAP2-3SL,TGV2-3N [Applicable wire size: 1.25 to 2.0mm^2]

外部接続（External connection）





出力部外部供給電源・負荷電源共通とした場合
When external power supply for output and load power supply are common.

端子番号 Terminal number	信号名 Signal name	端子番号 Terminal number	信号名 Signal name
TB1	DA	TB21	YD
TB2	DB	TB22	YE
TB3	DG	TB23	YF
TB4	SLD	TB24	Y10
TB5	+24V	TB25	Y11
TB6	⏚ (FG)	TB26	Y12
TB7	24G	TB27	Y13
TB8	Y0	TB28	Y14
TB9	Y1	TB29	Y15
TB10	Y2	TB30	Y16
TB11	Y3	TB31	Y17
TB12	Y4	TB32	Y18
TB13	Y5	TB33	Y19
TB14	Y6	TB34	Y1A
TB15	Y7	TB35	Y1B
TB16	Y8	TB36	Y1C
TB17	Y9	TB37	Y1D
TB18	YA	TB38	Y1E
TB19	YB	TB39	Y1F
TB20	YC	TB40	COM+
		TB41	CTL-